

SEM & GREENSTEERING MAINTENANCE OVERVIEW.

Instruction	First time: 4 - 12 weeks	50,000 km / 6 months*	300,000 km / 1 year*	Every 3 months	Annually
Manual lubrication turntables	×			×	
Automatic lubrication turntables**				N/A***	
Checking turntables above axle(s) for bearing play			×		×
Checking turntables kingpin module for bearing play			×		×
Checking bolts and nuts	×		×		
Visual inspection of and steering bar supports			×		×
Lubrication and checking the steering wedge					×
Checking kingpin	×	×		×	

* Whatever is reached first.

** Central lubrication must be assembled as of initial use.

*** The central lubrication ensures a continuous lubrication and therefore doesn't have a fixed interval such as for manual lubrication.